



USB_ON/OFF

CLK2 DAT2
TP19 TP21



TP49 SD_VDD

SD 2.0



SIM1

RST2 VDD2

